Viticulture Harvester Spares

Rod Set Up Specifications

Specifications for: G152

PUT HEAD IN NEUTRAL USING CENTRING BOLT

ENSURE SHAFT IS IN A NEUTRAL POSITION.

CLOSE HYDRAULIC HEAD COMPLETELY.

Front sticks should be 1200mm long from post.

Rear straight sticks should be 905mm long from post.

Adjust inner and outer dog bones so that sticks are tipping evenly and this is now centred.

Put in VHS Rods and adjust by pushing through alloy clamp but no more then 80mm.

This should give a nice straight edge that then can be refined to tip or front pick.

REMOVE HEAD CENTRING BOLT.

For all your grape harvester spare parts call Viticulture Harvester Spares
on 08 8568 2153
Visit www.viticultureharvesterspares.com.au to view our online shop or
email parts@viticultureharvesterspares.com.au

Viticulture Harvester Spares

Rod Set Up Specifications

Specifications for: G152

PUT HEAD IN NEUTRAL USING CENTRING BOLT

ENSURE SHAFT IS IN A NEUTRAL POSITION.

CLOSE HYDRAULIC HEAD COMPLETELY.

Front sticks should be 1200mm long from post.

Rear straight sticks should be 905mm long from post.

Adjust inner and outer dog bones so that sticks are tipping evenly and this is now centred.

Put in VHS Rods and adjust by pushing through alloy clamp but no more then 80mm.

This should give a nice straight edge that then can be refined to tip or front pick.

REMOVE HEAD CENTRING BOLT.

Specifications for: G108

PUT HEAD IN NEUTRAL USING CENTRING BOLT

ENSURE SHAFT IS IN A NEUTRAL POSITION.

CLOSE HYDRAULIC HEAD COMPLETELY.

Inner dog bones make 950mm centre to centre.

Outer dog bones make 720mm centre to centre.

Front sticks should be 800mm long from post.

Rear straight sticks should be 820mm long from post.

Adjust inner and outer dog bones so that sticks are tipping evenly and this is now centred.

Put in VHS Rods and adjust by pushing through alloy clamp but no more then 80mm.

This should give a nice straight edge that then can be refined to tip or front pick.

REMOVE HEAD CENTRING BOLT.

For all your grape harvester spare parts call Viticulture Harvester Spares on 08 8568 2153
Visit www.viticultureharvesterspares.com.au to view our online shop or email parts@viticultureharvesterspares.com.au