Viticulture Harvester Spares

G60KW Only Rod Set Up

The rod set up for the G60KW is as follows:
Neutralise the picking head and lock in with the locking bolt.
Loosen all picking post bushes..
Loosen all inner dog bone bushes.
Loosen all outer dog bone bushes.
Set up the front straight rods so they are 750mm long from the back of the post.
Set up the rear post straight rods so they are 800m long from the back of the post.
Adjust the inner dog bones until the back rods tip.
Adjust the outer dog bones until the front rods tip.
Set up two rods (one on each side) so they just overlap.
Now adjust the inner dog bones so you adjust the (pinch) or gap between the rods to what you normally would run. (between 30mm and 80mm gap is normal depending on what you are picking)
Now lock up all bushes, nuts and pins etc.
Remove the neutralising bolt.
Fit as many rods as required per side as long as the number per side are the same.
Run and test.

For all your grape harvester spare parts call Viticulture Harvester Spares
on 08 8568 2153
Visit www.viticultureharvesterspares.com.au to view our online shop or
email parts@viticultureharvesterspares.com.au